

ATTENTION 2026+ JL/JT OWNERS!

Temporary removal of the vehicle's crash brackets is required for all Clayton Off Road OVERLAND+ and PREMIUM lift kit installations. On most 2026 models, these brackets are located on both the front driver and passenger sides. Using an 18mm socket, remove the nine bolts securing each crash bracket to the frame:

- Three bolts located on the outer side of the frame
- Four bolts are positioned near the front wheel well
- Two bolts are located on the underside of the frame rail

The crash brackets should be reinstalled once the suspension installation is complete. Re-torque the tire deflector bolts to 148 ft-lbs.



Figure A: passenger/driver side crash bracket bolts to remove (3x on each side)



Figure B: 4x bolts near wheel well and 2x bolts on underside of frame

REV: A | DATE: 03/25/2026 | AUTH: KW