

**CLAYTON OFF ROAD  
COR-1908010  
JEEP WRANGLER PRO SERIES LONG FRONT UPPER CONTROL ARM  
(2007-2018, JK)**



NOTES: This product may require general welding, fabrication and automotive mechanic skills. Welding should only be done by a competent welder. Clayton Off Road implies no guarantees or warranties and is not liable for improper installation. Some grinding and fitment may be required when installing this product. Every vehicle varies slightly and some fabrication may be required. For more information please visit our website.

Refer to drawing view below and individual product part number instructions.

Step 1: Set as close to recommended length as possible with grease fitting up.

Step 2: Bolt the Giiro Joint end of the control arm into the frame bracket.

Step 3: Bolt the Johnny Joint end of the control arm onto axle.

Step 4: Tighten bolts at both ends.

Step 5: Make sure vehicle is at ride height and track is set.

Step 6: Set caster angle, 4.5 to 5.5 degrees of caster is recommended.

Step 7: Tighten jam nuts. (We recommend a 46 mm or 1 13/16" combination wrench for this. We also recommend cutting the box end off the wrench and getting a three foot piece pipe to put over the end of the wrench for leverage. Inserting a large screw driver between the joint body and the mount will hold the housing joint straight.)

Step 8: The Johnny Joints are pre greased so initial greasing is not required. The Giiro Bushings are maintenance free. (We do recommend greasing the joints every time you change your oils or grease other components on your vehicle. Use a hand grease gun not a pneumatic grease gun.)

**Recommended starting control arm length for 2.5" to 4.5" of lift is 35-1/2"."**

**Some adjustment of this measurement maybe performed for special applications as long as the length stays within the minimum and maximum lengths shown below.**

